

ASSEMBLY INSTRUCTIONS FOR PEGATEC STAND

The safety regulations must be strictly observed during assembly.

Use of protective gloves is recommended

Requested tools:

ZFor unpacking: knife For assembly: screw driver with PZ bit A small hammer to place the plastic wedges.

1. STEP

Open the packed product on a safety place in laid position. Cut the duct tape carefully. Remove the spacers and check all requested parts, they shall be undamaged. (1. picture)

2. STEP

Parts: sole element, middle element, head element, decoration panels, shelves, shelf holders, product holter consoles, metal and plastic parts for assembly. (2-3. pictures)





3. STEP

Turn the sole element and place the 4pcs distance screws. (4. picture)

4. STEP

Remove the protective foil from the sole element. (5. picture)

5. STEP

Put the middle element vertically on the sole element and fix it with metric screw and flang nut. (6. picture)

6. STEP

Put the head element on the middle element and fix it with the metric screws into the boreholes. (7-8. pictures)

7. STEP

Share out and fix the shelf holders consoles with hand clamp screw on the shelf holder. (9. picture)

8. STEP

Place the shelves, check the horizontally and fix them with a countersunk head screw to the shelf holder. (10-11. pictures)



9. STEP

Remove the foil from the head and middle elements. Place the side decor elements with regard to the place of plastic hammer elements. Fix the plastic decor elements with careful hits. (12. picture)

10. STEP

Put the head element on the self-glewing place. (13. picture)

11. STEP

Share out the product holder consoles with regard to size of products. (14. picture)

12. STEP

Put the products on the consoles. (15. picture)

